


Setup

If you want to change the display mode, follow the steps below.



On Screen Menu - The On Screen Menu is used to change settings such as slide duration, EXIF info, etc. as shown below:



Transferring Pictures from the PC to NuVue

Connect the USB cable to the NuVue then connect the other end to the USB port on the PC. After the frame is connected, a message will display on the screen of the NuVue.

Go to “My Computer” on your PC. You will notice that there are 4 more drive letters on your PC. This is from the card read on the NuVue. Each card slot represents 2 drive letters.

Locate the drive letter that represents your card, and drag and drop the desired picture to the card in the NuVue. After you have completed loading your pictures, disconnect the NuVue from the PC and view you picture.



NuVue 561

User Manual

Congratulations! You are the proud owner of a NuVue™ Digital Picture Frame. Boasting high-quality image resolution the NuVue™ is the perfect product for displaying your favorite digital photos. With its ease of use and configuration, you can now display all your favorite pictures or video files for everyone to see!

Package Contents

Before using the NuVue™, be sure to check all the accessories contained in the package. NuVue™ comes with the following items:

1. NuVue™ unit with desktop stand
2. A.C. Power Adapter
3. USB Cable
4. Composite TV Out Cable
5. User Manual

Specifications

Model	NV-561
Unit Size	6.5" (H) x 8.5" (W) x1.25" (D)
Display Area	3.25"H x 4.375"W
Resolution	320x234
Brightness	250cd/m ²
Contrast ratio	150:1
Viewing angle	45°L/45°R/15°B/35°T
Picture support	6MP
A.C. Adapter	AC110—240V (50HZ—60HZ)
Unit Input Voltage	12VDC@1.5A
Working Temperature	0°C - 50°C
Unit Weight	1.3 lbs.
Formats	JPEG
Media	CF/SD/XD/MMC/MS
Max Images	Based on media capacity
Default Start Mode	Auto Slide Show jpeg
Controls	Display time, EXIF On/Off, Transition style, Play/Stop/Pause/Menu

Connect

Use the guide below for power connection and media insertion.

